



## Deako

### Simple Motion Sensor & Timer

DS-SM1N-WHWH-UCQ

SKU: 169657    UPC: 850022963193

The Simple Motion Sensor & Timer Switch brings energy-saving efficiency and simple automation to any room in the house. It can automatically turn lights on when you enter a room—like when your arms are full of laundry—and automatically turn lights off when you leave with 10 or 20-minute timeout options..

#### Features

- In Occupancy mode, the light will turn on automatically when you enter the room. The light will then turn off automatically after no motion is detected for a set amount of time (10 or 20 minutes).
- In Vacancy mode, the light is turned on manually (by pressing the switch) but turns off automatically after no motion is detected for a set amount of time (10 or 20 minutes).
- The light can always be turned on or off manually by pressing the main button on the switch.
- The switch has two automatic timer settings: 10 and 20 minutes
- Only for lights that are controlled by one switch (single-pole)
- California Title 24 compliant