



Just Add
Power

Serial To IR Flux Capacitor

VBS-HDIP-IR

SKU: 58219 UPC: 683615347236

The Just Add Power Flux Capacitor IR Dongle provides IR control of endpoint devices through the Just Add Power 2G and 3G product lines.

It's all under control. Use the Flux Capacitor IR Dongle combined with Just Add Power drivers to control all of your IR devices over a single IP connection. Each IR Dongle becomes an additional IR port on the control system!

Features

- Connects to RS232 port on a Receiver or Transmitter
- Converts RS232 into an IR signal
- Compatible with Pronto and Global Cache IR codes
- Conveniently powered through Receiver USB port
- Compliancy: RoHS/FCC/CE
- Power supply: DC5V, 0.5A minimum USB micro