



Assure Pushbutton Lockset w/ Norwood RH Lever - Satin Nickel

YRC216-ZW2-NW-5-KD-619-RH

SKU: 72702 UPC: 08102300234

Keyed deadbolt with acrylic push button keypad. Single point lock. Latch bolt is operated by either lever at all times. Deadbolt activated by push button or key on outside or by thumb turn on inside. Interior lever retracts latch and deadbolt simultaneously.

Feature

- Single point lock.
- The latch bolt is operated by either lever at all times.
- The deadbolt is activated by either lever at all times. Deadbolt activated by push button or key on outside or by thumb turn on inside.
- The interior lever retracts the latch and deadbolt simultaneously.
- Lever: Norwood Style
- Pushbutton Keypad
- 5 1/2" Center to Center
- Keyed Different
- Right Handed